

Lower end injector & wear parts kits 20%:

Manual Reference	Part #	Description of Part
7	011913P	Inner Cylinder
14	212006 *Must specify material	O-ring
15	194004	Seal Retainer O-ring (Retainer Quad Ring)
17	212005 *Must specify material	O-ring
44	195909	Dosage Piston
51	011904	Shaft Assy
53	194344	Klipring
60	011849M *Must specify material	Hose Kit
61	195851	Outer Cylinder
66	212228 *Must specify material	O-ring
68	212002 *Must specify material	O-ring
72	195850	Adapter
72	190850	Remote Adapter
73	195855	Dosage Piston Guide
79	195911	Ratio Locking Pin
83	190741	Shaft Seal Spacer
91	212518 *Must specify material	O-ring
92	195861	Shaft Cap
93	193003	Capscrew 10-32 X 1/2" Ss Hex Head
94	212004 *Must specify material	O-ring

Kit A – Wear Parts Kit (dosage piston, O-ring)	011105V	14, 17, 44,
Kit B - Hose Kit	011849M	60
Kit C – Wear Parts Kit (Kit A, O-rings)	011106V	7, 14, 17, 44, 66, 68, 91, 94
Kit H – Motor Piston Assy (upper end kit)	011662UPS	9, 20, 21
Kit I - Remote Injection Kit (pg. 24)	012706	30, 31, 35, 36, 72
Kit M – Mounting Bracket Kit (mounting bracket, 2 pins)	011732	54, 55

