



# Lower end injector & wear parts kits 5%:

English

Kit A - Wear Parts Kit (dosage piston, O-ring)	011076V	14, 17, 44
Kit B - Wear Parts Kit (Kit A, shaft)	011077V	14, 17, 44, 52
Kit C - Wear Parts Kit (Kit A, inner cylinder, O-ring)	011074V	12, 14, 17, 37, 44
Kit D - Suction Tube Fitting Assy (poppet, washer, O-ring, spring, fitting)	011079V	10, 11, 12, 13, 80
Kit E - Wear Parts Kit (Kits C & D, inner cylinder, 2nd inner cylinder, shaft, pin, gasket)	011080V	10, 11, 12, 14, 13, 16, 17, 37, 44, 52, 80
Kit G - Lower End Complete Kit (Kit E, outer cylinder, ratio adjuster, O-rings, pin, filter, solution tube)	011081V	7, 10, 11, 12, 13, 14, 16, 17, 25, 26, 27, 37, 44, 52, 60, 61, 71, 79, 80, 82
Kit H - Motor Piston Assy (upper end kit)	011662S	9, 20, 21
Kit I - Remote Injection Kit	011762 (Viton) 011764 (EPDM)	Not Shown
Kit M - Mounting Bracket Kit (mounting bracket, 2 pins)	011732	54, 55

Ref. #	Part #	Description of Part
7	190031	Cylinder, Outer
10	194418H	Spring
11	194412	Fitting, Suction Tube, 3/8"
12	212120	O-ring
	*Must specify material	
13	011453A	Check Poppet W/Washer
14	212005	O-ring
	*Must specify material	
16	195709	Gasket
17	212005	O-ring
	*Must specify material	
25	011015	Suction Tube, 3/8" X 5'
26	195761	Anti Lock Gasket
27	011026	Filter For Suction Tube, 3/8" Id
37	195405	Inner Cylinder
44	010044P	Dosage Piston
52	195726	Shaft
60	212517W	O-ring
61	195428	Ratio Adjuster
71	194414	Nut, Suction Tube Fitting
79	195224	Interlock Pin
80	194415	Twistlock
82	195740	Shaft Seal Spacer



Lower End Assembly