


Lower end injector parts 0.2% - 2%:

Manual Reference	Part #	Description of Part
7	102840	Inner Cylinder
10	194418H	Spring
11	194417	Suction Tube Fitting 1/4" 20 Gal
12	212120 *Must specify material	O-ring
13	011453A	Poppet, Check W/Washer
14	212501 *Must specify material	O-ring
16	010016S	Gasket, Inlet/Outlet
17	195709	Gasket, Body To Lower End
25	010025	Suction Tube 1/4"Id X 5'
27	011017	Filter For Suction Tube, 1/4"Id
44	102725	Dosage Piston
51	190408	Lower Shaft
52	102007	Upper Shaft
61	194406P	Ratio Adjuster
64	212017 *Must specify material	O-ring
65	194310D	Interlock Pin
66	212025 *Must specify material	O-ring
67	012960	Outer Cylinder
71	194414	Nut Suction Tube Fitting
72	102720	Lower End Adapter
79	194410SS	Retainer Clip Bottom
80	194415	Twistlock



Lower End Assembly

