


# Lower end injector parts 1% - 5%:

Manual Reference	Part #	Description
7	102841	Inner Cylinder
10	194418H	Spring
11	194412	Suction Tube Fitting 3/8" 30 Gal
12	212120 *Must specify material	O-ring
13	011453A	Poppet, Check W/Washer
14	212005 *Must specify material	O-ring
16	010016S	Gasket, Inlet/Outlet
17	195709	Gasket, Body To Lower End
25	011015	Suction Tube 3/8"Id X 5'
27	011026	Filter For Suction Tube, 3/8"Id
44	102001	Dosage Piston
52	012210	Shaft Assembly
61	194406P	Ratio Adjuster
64	212017 *Must specify material	O-ring
65	194310D	Interlock Pin
66	212025 *Must specify material	O-ring
67	012962	Outer Cylinder
71	194414	Nut Suction Tube Fitting
72	102720	Lower End Adapter
79	194410SS	Retainer Clip Bottom
80	194415	Twistlock



Lower End Assembly

