

# Lower end injector & wear parts kits 2.5%:

Kit A – Wear Parts Kit (dosage piston and O-ring)	011850V	14, 17, 44
Kit B – Wear Parts Kit (Kit A, & shaft)	011945V	14, 17, 44, 51
Kit C – Wear Parts Kit (Kit A, inner cylinder and O-ring)	011850CV	7, 14, 17, 44, 64
Kit D – Hose Kit (O-ring, dip tube fitting, check valve, 2 adapters, clamp, hose, filter)	011849M	60
Kit F – Lower End Cylinder Kit (inner & outer cylinder, ratio adjuster, O-rings, retainer clip, pin, gasket)	011961V	7, 16, 61, 64, 65, 66, 67, 79
Kit H – Motor Piston Assy	011861	9, 21
Kit M – Mounting Bracket Kit (mounting bracket, 4 hex caps & nuts)	011432	56,57,58

Manual Reference	Part #	Description of Part
7	194404P	Cylinder, Inner
14	212005 *Must specify material	O-ring
15	194004	Seal Retainer, O-ring
16	010016S	Gasket
17	212005 *Must specify material	O-ring
44	010044P	Dosage Piston
51	194301F	Shaft
60	011849M	Hose Braid Kit
61	194406P	Ratio Adjustment Sleeve
64	212017 *Must specify material	O-ring, Inner Cylinder, Lower End
65	194310D	Pin, Upper Interlock
66	212025 *Must specify material	O-ring, Outer Cylinder, Lower End
67	194407P	Cylinder, Outer
79	194410SS	Pin, Narrow Interlock

